





ARM SYSTEM  -Make sure all protected windows & doors are closed. You should have a green “ready” light on the keypad.

Away Press 4 DIGIT CODE +  This will arm all devices including motion detectors.


Stay Press 4 DIGIT CODE +  This will arm all devices and automatically bypasses all motion detectors.

To Turn System Off Enter 4 digit code + 

QUICK ARM: AWAY.... PRESS # + 

STAY..... PRESS# + 

Door Chime On/Off Enter 4 digit code + 

Bypass a Zone Enter 4 digit code +  + two digit zone number you wish to bypass (02, 13, 22, etc.) Wait for bypass to appear then arm the system.

Change Mastercode Number

Enter current Mastercode ____ +8 +002+New 4 digit mastercode
(Add a new user?) 0=no 1=yes (Enter 1 to add a new user code. Enter 0 will change the existing user's code)
(Enter the authority level)....1 master 2 manager... 3 operator

Change or Add Additional Codes

(user #)
Enter current Mastercode ____ +8 +003 + New 4 digit code
Enter current Mastercode ____ +8 + 004 + New 4 digit code
.....
Enter current Mastercode ____ +80 + 20 + New 4 digit code

Add new user.... 0=no 1=yes the system will recognize that the user # is already in use and will prompt whether or not this is a new user. 0 will change the existing user's code

Delete a User Code

Enter current Mastercode ____ + 8 + user # + manager code
Okay to Delete?? 0=no 1=yes